

Locate the two wires going from the rectifier to the brushes, DO NOT USE THESE!! Cut one of the two excitation wires and connect as Shown
NORMAL WIRING, TO RETAIN THE HARMONIC WINDING

