

**INSTRUCTIONS TO REMOVE THE EXCITATION WINDING AND USE 120 VOLT MAIN WINDING TO EXCITE THE ST. ( HARMONIC WINDING)**

**Locate the two wires going from the rectifier to the brushes, LEAVE THEM CONNECTED!! Cut both excitation wires and connect as shown.**

